

NOTES:

- 1) THIS METHOD OF CONNECTION SHALL NOT TAKE PRECEDENT OVER USING TEES. THE APPLICATION SHOWN HERE IS FOR TAPPING EXISTING MAINS.
- 2) SADDLE SHALL BE ROMAC CB OR APPROVED EQUAL

